




Temperature-dependent miscibility of non-fluorinated ionic liquids in water

Daphne Depuydt



Ionic Liquids

Solvents that consist entirely of ions



Synthesis

- functional design of novel ILs


Thermomorphic behavior

- Investigation of temperature-dependent miscibility in water

HLLE

- Extraction of metal ions

Miscibility with water






Hydrophobic ILs



Hydrophilic ILs




Changing the nature of the ions
anion



cation





Miscibility with water



Addition of salts

Aqueous Biphasic Systems

Miscibility with water




Changing the temperature

Thermomorphic Ionic Liquids

Thermomorphic Behavior




= temperature-dependent miscibility of IL in water

- Dynamic and reversible phase change between homogeneous phase and liquid/liquid biphasic




Temperature-Dependent Miscibility

UCST





55 °C



72 °C

Temperature-Dependent Miscibility








UCST



Opportunity to extract rare earths

Temperature-Dependent Miscibility

LCST



Applications

Electrochemistry


Engineering

Analytics

Solvents



↳ Separation of metal ions

Conventional Solvent Extraction



Extraction of metal ions



HOMOGENEOUS LIQUID-LIQUID EXTRACTION



UCST

Extraction of metal ions

HOMOGENEOUS LIQUID-LIQUID EXTRACTION



Homogeneous region
5 °C

LCST

Biphasic system
25 °C

H₂O

IL

KU LEUVEN

Extraction of metal ions

HOMOGENEOUS LIQUID-LIQUID EXTRACTION

Metal ion	C_i (ppm)	C_{aq} (ppm)	D	%E	%S
Co^{2+}	6866	1278	4	81	99
Ni^{2+}	5578	286	19	95	99
Cu^{2+}	4480	128	34	97	58
Zn^{2+}	7466	285	25	96	91



→ %S = 99%




Extraction:
$$D = \frac{c_{in} - c_{aq}}{c_{aq}}$$

$$\%E = \frac{c_{IL}m_{IL}}{c_{IL}m_{IL} + c_{aq}m_{aq}} \times 100 \%$$

Stripping:
$$\%S = \frac{c_{ILbs} - c_{ILas}}{c_{ILbs}} \times 100 \%$$

Precipitation stripping with oxalic acid

Irving-Williams series:
Co < Ni < Cu > Zn



Acknowledgements

- Prof. K. Binnemans
- Prof. W. Dehaen



agentschap voor Innovatie
door Wetenschap en Technologie

- Arne & Hendrik
- Lab of Inorganic Chemistry

Thank you for your attention

