




Applying ionic liquids in the pre-processing of rare earths concentrates



EXIL

April 2016, Poznań

Dr. Mercedes Regadío
Prof. Koen Binnemans



- Introduction
 - Rare earth elements (REE)
 - Solvent extraction (SX)
 - Objective
- Materials and methods
 - ILs and leaching aqueous solution
 - Split-anion solvent extraction (SX)
- Results and discussion
 - ILs as organic solvents (undiluted-pure IL)
 - ILs as diluents of neutral extractants
- Conclusions

INTRODUCTION

- Rare earth elements (REE)
 - Magnetic, optical, spectroscopic ... properties
 - Critical metals (EU)

HEAVY Rare Earth Elements
LIGHT Rare Earth Elements
by Geology.com

H																		He
Li	Be																	
Na	Mg																	
K	Ca	Sc	Ti	V	Cr	Mn	Fe	Co	Ni	Cu	Zn	Ga	Ge	As	Se	Br	Kr	
Rb	Sr	Y	Zr	Nb	Mo	Tc	Ru	Rh	Pd	Ag	Cd	In	Sn	Sb	Te	I	Xe	
Cs	Ba	La-Lu	Hf	Ta	W	Re	Os	Ir	Pt	Au	Hg	Tl	Pb	Bi	Po	At	Rn	
Fr	Ra	Ac-Lr	Rf	Db	Sg	Bh	Hs	Mt										
<div><div>La Ce Pr Nd Pm Sm Eu Gd Tb Dy Ho Er Tm Yb Lu</div><div>Actinides</div></div> <div>Ac Th Pa U Np Pu Am Cm Bk Cf Es Fm Md No Lr</div>																		


<http://www.traderslog.com/wp-content/uploads/2011/06/ree1.jpg>

- Increasing demand




1 kg of Nd, Pr, Dy for 1 hybrid car

2.4 g of REE for one laptop computer




Solvent extraction, SX


- Ore mining and enrichment of the valuable minerals → *concentrates*
- Leaching to dissolve REE → *Pregnant Leach Solution (PLS)*
- Forcibly stirred with an immiscible organic solvent → *Loaded organic phase* *
- Disengagement of the two phases
- The different elements distributes differently
- Scrubbing aqueous solution *
- Stripping aqueous solution * (reverse)
 - Aq. phase: metal recovery (electrowinning, precipitation)
 - Org. phase: for recycling




Pilot scale mixer-settler units




Pilot scale mixer-settler units



Pilot scale mixer-settler units



Pilot scale mixer-settler units



Sustainability



Safety Data Sheet Kerosene



SECTION 1. PRODUCT AND COMPANY IDENTIFICATION			
Product name	Kerosene		
Synonyms	Dual Purpose, K1, Dyed K1, Kerosene, Low Aromatic Feedstock, SPK Solvent, AVIS, Grade Fuel Oil (DFA), Heater Oil, Range Oil, Coal Oil, K2, Gas Oil, 88810004861		
SDS Number	88810004861	Version	2.16
Product Use Description	Fuel		
Company	For: Tesoro Refining & Marketing Co. 78100 Ridgewood Parkway, San Antonio, TX 78258		
Tesoro Call Center	(877) 763-7676	Chemicals (Emergency Contact)	(800) 424-9300
SECTION 2. HAZARDS IDENTIFICATION			
Classifications	Flammable Liquid - Category 2 Aspiration Hazard - Category 1 Skin Irritation - Category 2 Specific Target Organ Toxicity (Single Exposure) - Category 3 Chronic Aquatic Toxicity - Category 2		
Pictograms			
Signal Word	Danger		
Hazard Statements	Flammable liquid and vapor. May be fatal if swallowed and enters airways - do not sip by mouth. Causes skin irritation. Extended or prolonged skin contact can cause skin irritation and dermatitis. May cause drowsiness or dizziness by inhalation. May cause irritation of respiratory system. Toxic to aquatic life with long lasting effects.		
Precautionary statements	1. Keep away from heat, sparks, open flames, welding and hot surfaces.		

Safety Data Sheets (SDS)

SECTION 1-IDENTIFICATION

Product name: Toluene

Other names:-

Proper shipping name: Toluene

Recommended use of the chemical and restrictions on use:

The major use of toluene is as a mixture added to gasoline to improve octane ratings. Used as a solvent for paint, resins, lacquers inks & adhesives. Component of solvent blends and thinners. Used in the manufacture of chemicals, dyes, explosives, benzoic acid. Some grades of toluene may contain traces of xylene and benzene.

The use of a quantity of material in an unventilated or confined space may result in increased exposure and an irritating atmosphere developing. Before starting consider control of exposure by mechanical ventilation.

WARNING: Intentional misuse by concentrating/inhaling contents may be lethal.

Manufacturer/Supplier Name: Taiwan SM Corp., Kaohsiung plant

Address: NO.7, Industrial 1st Rd, Lin-Yuan Kaohsiung County 83203, Taiwan, R.O.C.

Phone No.: 886-7-6414511

Emergency phone No./Fax No.: 886-7-6414511 Ext. 221 (on duty), 886-7-6414517 (off duty)/886-7-6423828

SECTION 2-HAZARDS IDENTIFICATION

GHS Classification:

Flammable Liquid Category 2
 Acute Toxicity (Oral) Category 4
 Skin Corrosion/ Irritation Category 2
 Serious Eye Damage/ Eye Irritation Category 2
 Specific Target Organ Toxicity Repeated Exposure Category 2
 Hazardous To The Aquatic Environment (Acute) Category 3
 Aspiration Hazard Category 1

GHS Label elements:

Hazard symbols



Signal word

Danger

Hazard statements

Highly flammable liquid and vapor
 Harmful if inhaled
 Causes skin irritation
 Causes serious eye irritation
 May cause damage to organs through prolonged or repeated exposure.
 May cause long lasting harmful effects to aquatic life.
 May be fatal if swallowed and enters airways.

Precautionary statements

Use only in well ventilated area.
 Control of exposure by mechanical ventilation in an unventilated or confined space.
 Avoid breathing vapors and contact with skin and eyes.
 Wear breathing apparatus/protective gloves/face protection.
 Store in well-ventilated place.
 Disposal must be in accordance with applicable federal, state, or local regulations.

Other hazards: -

SECTION 3-COMPOSITION/INFORMATION ON INGREDIENTS

CAS No.	Chemical Name	wt% by weight	EINECS No.
00108-88-3	Toluene	97.0 min.	203-625-9
Synonyms	Methylbenzol; Methylbenzene; Toluol; Phenylmethane		

Fluorine-free ionic liquids:

- Low volatile
- Non flammable
- Electrically conductive: static electricity is not accumulated

57-71

Rare

sustainable exploitation



- 
- BASF**
We create chemistry




1. Pure ILs: **Cyphos101NO₃**[P66614]⁺[NO₃]⁻ **A336NO₃**[N8881]⁺[NO₃]⁻

- A336: REEs extractant earlier than it was known as an IL.
- A336 as pure IL (solvent) or as diluent, NOT diluted in molecular diluents

2. ILs as diluents of neutral extractants: TBP, Cyanex[®] 923



Element	Percentage
La	29%
Ce	63%
Pr	8%



HEAVY Rare Earth Elements
LIGHT Rare Earth Elements
by Geology.com

H																	He
Li	Be											B	C	N	O	F	Ne
Na	Mg											Al	Si	P	S	Cl	Ar
K	Ca	Sc	Ti	V	Cr	Mn	Fe	Co	Ni	Cu	Zn	Ga	Ge	As	Se	Br	Kr
Rb	Sr	Y	Zr	Nb	Mo	Tc	Ru	Rh	Pd	Ag	Cd	In	Sn	Sb	Te	I	Xe
Cs	Ba	La-Lu	Hf	Ta	W	Re	Os	Ir	Pt	Au	Hg	Tl	Pb	Bi	Po	At	Rn
Fr	Ra	Ac-Lr	Rf	Db	Sg	Bh	Hs	Mt									


Lanthanides

La	Ce	Pr	Nd	Pm	Sm	Eu	Gd	Tb	Dy	Ho	Er	Tm	Yb	Lu
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Actinides

Ac	Th	Pa	U	Np	Pu	Am	Cm	Bk	Cf	Es	Fm	Md	No	Lr
----	----	----	---	----	----	----	----	----	----	----	----	----	----	----



- Ethylene glycol (EG): polar organic solvent to decrease the H_2O surrounding the REE ions



Method: SX via Split-anion

- Organic phase, IL (lighter-upper): anions for complexing and extracting the REEs (NO_3^-) (solvating extraction, no anion exchange)
- Aqueous phase, feed solution (heavier-lower): other anions (Cl^-) that:
 - ✓ form weakly complexes with REE
 - ✓ stronger affinity to stay in the aqueous phase
- Order of preference for water: Hofmeister series

$\text{SO}_4^{2-} > \text{HPO}_4^{2-} > \text{CH}_3\text{COO}^- > \text{Cl}^- > \text{Br}^- > \text{ClO}_3^- > \text{I}^- > \text{NO}_3^- > \text{ClO}_4^- > \text{SCN}^-$



Mixed until equilibration in TMS-200 turbo thermoshaker, followed by centrifuging (3500 rpm, 5 min) to phase disengagement

Display the extraction data of an element compared to other elements

- Distribution ratio (D)
- Extraction percentage (E)
- Separation factors ($\alpha_{A,B}$, $\alpha_{A,B+C}$)

$$D_A = \frac{[A]_{IL}}{[A]_{aq}} = \frac{[A]_{0,aq} - [A]_{eq,aq}}{[A]_{eq,aq}} \times \frac{V_{aq}}{V_{IL}} \quad \Downarrow \quad \frac{[A]_{0,aq} - [A]_{eq,aq}}{[A]_{eq,aq}}$$

If volume ratio a:o = 1

Metal distributions and kinetics can be adjusted varying different parameters:

- IL
- Temperature
- Mixing speed
- $[Cl^-]$
- Initial REE concentrations
- pH
- Composition of the org. ph.
- Polar organic solvent (aq. ph.)



$$\%E_A = \frac{D_A}{D_A + \frac{V_{aq}}{V_{IL}}} \times 100 = \frac{[A]_{eq,IL} V_{IL}}{[A]_{eq,IL} V_{IL} + [A]_{eq,aq} V_{aq}} \times 100$$

If volume ratio a:o = 1 →

$$\%E_A = \frac{[A]_{0,aq} - [A]_{eq,aq}}{[A]_{0,aq}} \times 100$$

$$\alpha_{A,B} = \frac{D_A}{D_B}$$

Solutes A and B are those that make $\alpha > 1$

If volume ratio a:o = 1 →

$$\alpha_{A,B} = \frac{[A]_{IL}/[A]_{aq}}{[B]_{IL}/[B]_{aq}}$$



$$\alpha_{A,B+C} = \frac{D_A}{D_{B+C}}$$

$$\frac{[A]_{IL}/[A]_{aq}}{([B]+[C])_{IL}/([B]+[C])_{aq}}$$

If volume ratio a:o = 1

Results: ILs


- IL
- Temperature
- Mixing speed
- [Cl⁻]
- Initial REE concentrations
- pH
- Composition of the org. ph.
- Polar organic solvent (aq. ph.)




- Extraction of REE with both ILs is possible
- Reversed sequence: %E Ce > %E Pr
- A336NO3: lower extraction capacity, but higher $\alpha_{A,B}$ (more hygroscopic)
A336NO3 formed emulsions


Effect of T, rpm, [Cl⁻], pH_{initial}

- Key parameters: mixing speed and chloride concentration
- Selectivity in the separation of La+Ce from Pr on intermediate %E (40-60%)
 - high excess of REE compared to the IL capacity to extract them enhance the competition between REE to form complexes and extract first the ones that show higher affinity to nitrates.




Effect of REE concentrations

- The decrease of % E is lower than that what would correspond 
- Difficult to reach the **theoretical** maximum load capacity and, thus, high [REE]s in the aqueous phase are needed.
- \uparrow Higher $\alpha_{La+Ce,Pr}$ if the overall extraction is hindered:
 \downarrow extraction is hindered:
 - increasing the [REE]
 - decreasing the [chloride]





Norra Kärr,
TREE 7-35 g/L (0.05-0.25 M)




Effect of two neutral extractants in both ILs

Also similar for both ILs



TBP (1-20 m%)



Initial feed solution




Cyanex® 923 (1-20 m%)



TBP no effect.

Low extraction values ($D < 0.4$, $E \rightarrow 20-30\%$, $\alpha_{A,B} \rightarrow 1.2$)



Only at 20 m% TBP, %E of Pr > %E of La, Ce

- Increase of %E:




Phosphine oxides have high Gutmann donor number, resulting in stronger interactions with the Lewis acidic REE-nitrate complex

- Extraction sequence is reversed back to a positive order

%E of Pr > %E of Ce and La


Reduction of the organic phase and extraction stages needed

The separation factors follow a bell curve




Effect of [REE] and organic phase composition

- Selectivity increases with the [TREE]
- With TBP/IL \rightarrow less efficient system than Cyanex[®] 923




High affinity of Cyphos+20% Cyanex[®] 923, towards Pr at high [REE]
(generally, in chloride routes via solvation, the $\alpha_{La,Ce}$ 1.6)

RESULTS: EG IN THE AQ. PH.



7 g/L TREE
10 wt% Cyanex 923




- Increment of the extraction, but its effect is irrelevant compared to the extractant dissolved
- Decrease of the separation factors

~~A336NO₃~~

~~TBP~~

~~EG~~

- Cyphos101NO₃ with 20% Cyanex[®] 923 (org. ph.) and 5 M Cl⁻ (aq. ph.) to separate Pr from La and Ce.
40 g/L TREE: 70% E Pr, vs. 34% E Ce, La
- Possibility of using neutral extractants in SX from chloride solutions.
- Cyanex[®] 923 diluted in both ILs is a synergistic agent for SX.
- At higher [REE], better selectivity in Cyphos101NO₃.
Competition to form complexes that can be extracted from the aq. to the org. phase.



EXIL

cost
EUROPEAN COOPERATION
IN SCIENCE AND TECHNOLOGY

Special thanks to:

- Laboratory of Inorganic Chemistry
- COST Organising Committee
- All of you for your attention



KU LEUVEN