



Sm/Co separation by solvent extraction with ionic liquids

Simona Sobekova Foltova

Promoter: Prof. Dr. Koen Binnemans

Co-promoter: Dr. Tom Vander Hoogerstraete

Sm/Co separation by solvent extraction with ionic liquids:

SmCo magnets




- Method
Solvent extraction with ionic liquids
- Results
Three solvent extraction systems were compared:
 - [A336][SCN]
 - [A336][Cl]
 - [A336][NO₃]from chloride aqueous media
- Next steps in my research plan

My goals

SmCo magnets:

1. Solvent extraction with undiluted ionic liquids.
2. Scale up to the continuous process (mixer-settler).

TARGET: To reach a high purities of recovered metal oxides:
REEs ($\geq 99.5\%$) and Co ($\geq 99.0\%$).




Method

Solvent extraction:

ORGANIC PHASE




↓ density liquid



AQUEOUS PHASE

↑ density liquid


Organic phase = IONIC LIQUID



Aqueous phase = ↑ conc. CHLORIDE SOLUTION

SmCo magnets:

- Sm
- Co
- Fe
- Cu
- Zr



Synthetic metal solution:

	c [g/L]
REE { Sm	95
transition metals { Co	98
Cu	8

Ionic liquids in solvent extraction

Ionic liquids are organic salts, which consist entirely of ions.



- + Non-volatile or very low-volatile.
- + Can be used undiluted.
- + Non-flammable.
- + No risks of electrostatic ignition.
- + Safer work environment.


- Higher viscosity.
- + Elevated **temperatures** lower the viscosity !

Extraction experiments

Conditions: O/A = 1, 40 °C, 2 000 rpm, 2 h
(Turbo Thermo Shakers TMS-200).

Metal analysis: Total Reflection X-ray Fluorescence (TXRF).

System [A336][SCN]



System [A336][SCN]

Problems related to thiocyanate

[A336][SCN]
stability

The precipitation stripping with NH_4OH leads to errors in measuring the metal concentrations, insoluble metal hydroxides are formed.

▼ Formation of precipitates.



Thiocyanate is not stable in the presence of strong acids/basis, elevated temperatures and is photosensitive [1], [2].



◀ Fresh (left) and 5 months old (right) solution of NH_4SCN .

- [1] Acidic aqueous decomposition of thiocyanogen
Jon J. Barnett, Michael L. McKee, David M. Stanbury, *Inorganic Chemistry* **43** (16), 5021-5033 (2004).
- [2] Studien über das freie Rhodan
E. E. Soderback, *Justus Liebigs Ann. Chem* **419**, 217–321 (1919).

System [A336][Cl]

Co and Cu extracted to ionic liquid (organic phase).

%E = 99.9% Co
%E = 99.3% Cu
%E = 25.5% Sm

1. EXTRACTION

with 3.6 M CaCl_2

%Sc = 45.7% Sm
% Sc = 0.1% Co
% Sc = 0.1% Cu

2. SCRUBBING

with 4 M CaCl_2

3. STRIPPING

with water

Samarium remains in the aqueous phase, but 25.5% Sm is co-extracted.

System [A336][NO₃]

Co and Cu extracted to ionic liquid (organic phase).

%E = 99.8% Co
%E = 99.3% Cu
%E = 60.8% Sm

1. EXTRACTION

with 3.6 M CaCl₂

%Sc = 52.8% Sm
% Sc = 0.1% Co
% Sc = 0.6% Cu

2. SCRUBBING

with 4 M CaCl₂


3. STRIPPING

with water


Samarium remains in the aqueous phase, but 60.8% Sm is co-extracted.

System [A336][NO₃]

Extraction



Loading at 3.6 M CaCl_2




Distribution ratio:

$$D_{Me} = \frac{[Me]_{IL}}{[Me]_{aq}}$$

Extraction efficiency:

$$\%E_{Me} = \frac{[Me]_{IL}}{[Me]_{aq} + [Me]_{IL}} \times 100$$


Co



Structure of the formed complexes

Extended X-ray Absorption Fine Structure spectroscopy (EXAFS).

The Dutch-Belgian Beamline (DUBBLE, BM26A) at the European Synchrotron Radiation Facility in Grenoble (France):



Data modeling in the program Viper:


Fourier transform and model of the $[\text{CoCl}_4]^{2-}$ complex in $[\text{A336}][\text{Cl}]$.

Summary of results

Extraction system	Extraction results		Complexes formed		Associated problem
	Not extracted	Extracted	REE	Transition metals	
[A336][SCN] from chloride media at 1.2 M CaCl ₂	100% Sm	Co, Cu *	[Sm(SCN) ₈] ⁵⁻	[Co(SCN) ₄] ²⁻ [Cu(SCN) ₄] ²⁻	[A336][SCN] stability
[A336][Cl] from chloride media at 3.6 M CaCl ₂	~ 75% Sm	Co, Cu ~ 25% Sm co-extracted	[Sm(H ₂ O) ₉] ³⁺	[CoCl ₄] ²⁻ [CuCl ₄] ²⁻	[A336][Cl] selectivity
[A336][NO ₃] from chloride media at 3.6 M CaCl ₂	~ 40% Sm	Co, Cu ~ 60% Sm co-extracted	[Sm(NO ₃) ₅] ²⁻	[CoCl ₄] ²⁻ [CuCl ₄] ²⁻	[A336][NO ₃] selectivity

* Co and Cu are preferentially extracted before Sm.

Phase disengagement



overhead stirrer
(WiseStir® HS-30D)

contact thermometer
(IKA® Yellow Line TC1)

250 mL beaker

silicon oil bath

heating plate
(IKA® RCT Basic)



O/A = 1,
2 min stirring

SETTLING TIME



Addition of salt (0, 1, 2, 4 M CaCl_2).
Stirring speed (200, 300, ... 700 rpm).
Temperature (22, 32, ... 82 °C).
Position of stirrer (aqueous / organic phase).
Kind of stirrer:




Next steps in my research plan

2. Scale up to the continuous process (mixer-settler).

What is innovative:

- Using undiluted ionic liquids.
- Solvent extraction as a continuous process for SmCo magnets recycling.



Acknowledgements

Promoter: Prof. Dr. Koen Binnemans
Co-promoter: Dr. Tom Vander Hoogerstraete

The research leading to these results has received funding from European Community's Horizon 2020 Programme ([H2020/2014-2019]) under Grant Agreement no. 674973 (MSCA-ETN DEMETER).

Project website: <http://etn-demeter.eu/>.



Thank you for your attention!

Simona.Sobekova@kuleuven.be